


# User Guide Katana Bluetooth Headphones



## OVERVIEW / CONTENTS

- **Moki Katana Bluetooth Headphones**
- USB to MicroUSB charge cable
- 3.5mm to 3.5mm audio cable
- User Guide



**TAP** - DECREASE VOLUME  
**HOLD 2 SECS** - RESTART TRACK  
**HOLD AGAIN** - PREVIOUS TRACK



**TAP** - INCREASE VOLUME  
**HOLD 2 SECS** - NEXT TRACK



**WHEN OFF:**  
**HOLD 1 SEC** - POWER ON  
**HOLD 3 SECS** - ENTER PAIRING MODE  
**WHEN ON:**  
**TAP** - PLAY/PAUSE  
**DOUBLE TAP** - REDIAL LAST # CALLED  
**HOLD 3 SECS** - POWER OFF

## CHARGING

*Please charge headphones before first use*

Connect the supplied charge cable to a USB port on a PC or USB charge adaptor. Confirm orientation and connect the MicroUSB to the port on your headphones.

The LED on the headphones will glow solid RED indicating the headphones are charging. Depending on the power of the charge port used, charge time will be around 1.5 - 2.5 hours.

When headphones are fully charged the LED will turn off. Disconnect charge cable.

*Note: Headphones will not operate if charge cable is still connected.*



## PAIR WITH BLUETOOTH DEVICES

*You must pair your Moki headphones with a Bluetooth device before it can be used wirelessly.*

You only need to pair your headphones to each play device once. They will automatically reconnect to each device when turned on in their vicinity. If two or more devices are available, the last device paired will be the one that reconnects.

## FIRST TIME USE / PAIR TO NEW DEVICE

On your *Bluetooth* play device go to **\*"Settings"** >> **"Bluetooth"** - turn on *Bluetooth*

*Play device should automatically start searching for new play devices. (Some older players may require you to select "search for / add new device")*

**\*With the headphones off, HOLD the "Play / Pause button for about 5 seconds until the LED starts blinking RED / BLUE which indicates it is now searching for a new Bluetooth device. (If headphones do not pair with a new device within 90 seconds they will enter "Standby mode")**

**\*On your phone or play device under "Bluetooth" you will see MOKI KATANA listed under "Available devices"**

**\*Select MOKI KATANA on your device to pair your headphones (older devices may require a code to complete pairing. Enter "0000" if requested).**

**\*When pairing is successful the LED on your headphones will slowly blink blue.**

Moki Katana headphones may be paired to PCs (dongle required) and laptops with *Bluetooth* capability. Go to your computers' *Bluetooth* settings and follow the prompts to connect in a similar way as described above. After pairing ensure the "Sound Output" is set to "Play through *Bluetooth*", (not "Internal Speakers"). Some computers may require *Bluetooth* audio output to be enabled each time you connect.

## SPECS

**Speaker Drivers:**  $\varnothing 40\text{mm}$   
**Impedance:** 64 $\Omega$   
**Sensitivity:** 112dB @1KHz  
**Frequency response:** 20Hz - 20kHz  
**Charging:** MicroUSB cable

**Bluetooth Specs:**  
**Bluetooth Version:** V4.1 +EDR  
**Earcup controls:**

Volume control - Up / Down,  
Track control - Previous / Next / Restart  
Play control - Pause / Play  
Voice Call Controls - Answer / End + Voice call option  
**Range:** 10m  
**Play time:** Approximately 8 hours  
**Talk time:** Approximately 10 hours